



SUPER MULTI-PURPOSE WALLPAPER PRIMER™

LA-822

WALLPAPER PRIMER

PRODUCT

DESCRIPTION: A versatile and transparent sealer for porous flat surfaces where vinyl wallpaper will be applied, this primer will help to give wallpaper a better adhesion to the wall.

BASIC USES:

Seals porous flat surfaces where vinyl wallpaper is to be applied, primes new and dry plaster walls when using glass, ceramic tile or plastic laminates, and provides better adhesion when new wallpaper is applied on top of the old one.

PRODUCT

ADVANTAGES:

- * Transparent
- * Water resistant
- * Easy to use
- * Non-staining
- * Water cleanup
- * Permanent

TECHNICAL DATA

Percent Solids:	50.00 ± 1% by weight 46.00 ± 1% by volume	Finish:	Transparent
Weight/Gallon:	8.93 ± 0.5 lbs.	Viscosity:	1,750 – 1,800 cps.
Flash Point:	Non-flammable		
Drying Time:	To touch: 30 minutes To topcoat: 2 hours	Theoretical Coverage:	250 sq. ft./gal.
Recommended Film Thickness:	3 mils dry, 6 mils wet.	Sizes:	5 gallons 1 gallon
Thinning:	Not normally recommended, but if necessary, add water up to 1/2 pint per gallon.		

Surface Preparation: All surfaces must be clean, dry and free of contaminants such as dirt, grease, mildew, oil, rust, loose or badly cracked paint. Fill cracks and nail holes with *LANCO® Vinyl/Acrylic Spackling Compound SC-101* and let dry two hours before applying primer.

Mildewed Surfaces: Any existing mildew on the surface must be killed and removed prior to the application of this product. Any mildew not removed may continue to grow. Using a long-handled brush, scrub mildewed surface with a brush and a mixture of one quart of household bleach and three quarts of warm water. Rinse completely and let dry.

Directions:

- (1) Clean surface. Wash greasy areas with detergent and allow to dry.
- (2) Apply a thin coat of *LANCO® Super Multi-Purpose Wallpaper Primer™ LA-822* with brush or roller.
- (3) Allow time to dry before hanging wallcovering (1/2 to two hours, depending on temperature and humidity). Do not use if wall temperature is below 40°F (5°C).
- (4) Clean all skills and tools immediately with water — dry adhesive is hard to remove.
- (5) Install vinyl wallcovering using *LANCO® Super Vinyl Wallpaper Adhesive™ LA-622*.

Method of Application:

BRUSH: Use a good quality nylon or polyester brush.

ROLLER: Use a *LANCO® All-Purpose 3/8" Nap Roller PA-566*.

Coverage: On smooth surfaces, 250 sq. ft. per gallon. On rough surfaces, coverage will be reduced.

Cleanup: Clean all equipment immediately after use with warm soapy water.

Caution: Do not take internally. Close container after each use. Keep out of reach of children. Do not use when temperature is below 40°F (5°C). Do not expose to freezing temperatures. Use only with adequate ventilation.

Notice: The technical data contained herein are true and accurate to the best of our knowledge. Published technical data and instructions are subject to change without prior notice.

M.S.D.S.: Available upon request.