

Cove Base Adhesive KA-549 Super Cove Base Adhesive

Description:

Supreme Flooring Adhesive™ is a white acrylic latex adhesive designed specially for installing rubber or vinyl cove base to almost any clean, dry and structurally sound interior wall surface. It will holds cove base in a vertical position and aids in wrapping corners.

Product Advantages:

- Good adhesion to construction materials
- Water resistant
- Water cleanup
- White mastic
- Multi-purpose

Use:

Cove Base Adhesive™ is excellent for the installation of rubber and vinyl cove base, cork wall panels and tiles; can be used over painted walls, gypsum drywall, plywood, plaster, wood, concrete and brick.

Surface Preparation:

All surfaces must be dry, clean and free of contaminants such as dirt, grease, loose or badly cracked paint.

Product Data:		
	Product Type:	Acrylic latex
	Finish color:	White
	Solids (%):	63 ± 2 by weight 54 ± 2 by volume
	Weight/Gallon:	10.19 lb ± 0.05 (4.62 kg ± .02)
	Drying time:	24 hours
	Coverage:	240 ft./gal. @ 4" (73.1 m/gal.@ 4")
	Sizes:	1 gallon 1 quart
	VIscosity:	200,000- 225,000 cps
	Percent Pigment by weight:	25 ± 2%
	Specific gravity:	1.48

Notice: The technical data contained herein are true and accurate to the best of our knowledge. Published technical data and instructions are subject to change without prior notice.

S.D.S.: Available upon request.

Application with a Trowel:

- 1. For outside corners, use a sanding block, wood rasp or sharp knife to cut a V-notch about 1/2 the thickness of the cove base on the back of the cove where the corner will fall. For inside corners, also cut through about 1/2 of the thickness from the backside. In addition, cut a small V-notch in the foe of the cove where it fits the corner, directly opposite the notch at the back.
- 2. Spread Cove Base Adhesive on the back of the cove base with a 1/8" V-notched spreader.
- 3. Set the cove base in place immediately, pressing it firmly to the wall by rubbing across the front with a clean cloth or roller. Stubborn spots may need further rubbing after five or ten minutes. Rub or roll toward the previously installed section to help assure a tight fit.
- 4. Fresh adhesive smears on the surface of the cove base or wall should be removed with a cloth dampened in clean water. Use Mineral Spirits MS-107, if adhesive is dry, carefully fallow warnings on solvent container.

Directions for Cork Wall Panels & Tiles:

- 1. Clean wall surfaces as recommended, and patch holes or depressions with Spackling Compound SC-101; let dry two hours and remove high spots if they prevent a level surface. Use a vacuum cleaner to clean cork dust from panels.
- 2. Follow the instructions of the cork manufacturer or brochure to plan the positioning of the cork on the wall for best appearance.
- 3. Apply Cove Base Adhesivedirectly onto the wall surface to be covered, using a notched spreader. Spread only an area of such size that cork can be placed into wet adhesive within thirty minutes.
- 4. Place cork panel or tile in position on wall and press into adhesive. Use a rubber wall roller and roll thoroughly in both directions to assure contact with adhesive and expel any air bubbles.

Limitation: Do not use over vinyl wall coverings.

Coverage: Approximately 60 square feet per gallon.

Cleanup: Clean all equipment immediately after use with warm water.

Precaution: While this adhesive is freeze-thaw stable to 10oF (-12oC), it is still necessary to protect from freezing to avoid excessively low temperature or multiple freeze-thaw cycles. Condition the area to be installed, adhesive and cove base at 65oF (18oC) or above 24 hours before and after installation.

Caution: Do not take internally. Use only with adequate ventilation. Keep out of reach of children.use. Keep out of reach of children. Use only with adequate ventilation. Product must be used within one year of purchase.

Limited Warranty: Manufacturers' liability in connection with the safety of this product extends only to the replacement value if it should fail to comply with quality standard or specifications. Protect from freezing.

[•] CARIBBEAN & SOUTH AMERICA • Urb. Aponte #5, San Lorenzo, Puerto Rico USA 00754 • Tel. (787) 736-4221 Fax (787) 736-5313